







The diagram illustrates the electrical connections for a car stereo system. Key components and their connections include:

- Power Source (電源プラグ):** Connected to a 50/60Hz power source.
- Power Board (電源基板):** Contains a fuse (FU1 3A-FUSE) and a transformer (TH001).
- Amplifier and Tuner:** Includes a tuner (TH001) and an amplifier (TH001) with various capacitors and resistors.
- Speakers:** Connected to the amplifier output through a speaker cable (スピーカー).
- Antenna and Radio:** Includes a radio antenna (ラジオアンテナ) and a radio tuner (ラジオチューナー).
- Control and Display:** Includes a control unit (コントロールユニット) and a display (ディスプレイ).
- Wiring Details:** The diagram shows the internal wiring of the car's body, including the battery, ground, and various control lines.



- ※1 HA接続コード：部品番号〔SP-HAC1〕
- ※2 標準アダプター：HA-S100TSA
- ※3 RACアダプター：PSC-6RAD
- ※4 無線LAN接続アダプター：SP-WL2
- ※5 HEMSアダプター：SP-EM1

